



X-STRIKE CO₂ KIT

USER INSTRUCTIONS AND IMPORTANT SAFETY INFORMATION

IMPORTANT: Please completely understand all user instructions and safety information before using this product.

TOOLS REQUIRED

4mm Allen wrench

8mm wrench for **CARBON** and **SUPER WINGS**.



INSTALLATION

DELTA WING 100 and **200**. The **X-STRIKE** fits between the cage and the spacers. Replace the two 22 mm screws from the **DELTA WING** with the two long 30 mm screws that were included with the **DELTA WING**. Tighten to 30 in.lbs (3.4 NM) of torque.

CARBON and **SUPER WINGS**. Mount the **X-STRIKE** on to the rear of these Wings. Pass the two included 15mm long screws through the **X-STRIKE** mount, through the two holes in the rear of the Wings and add the two locknuts on the inside. Tighten to 30 in.lbs (3.4 NM).

FRAME MOUNT. Using the two 15mm screws included pass them through the existing cage, then the **X-STRIKE** mount and into the frame. Tighten to 30 in.lbs (3.4 NM).

WARRANTY

As with any high-tech racing gear, you need to routinely check for loose hardware, cracks or other damage and replace as required.